



Front Panel

- F1. Power Button
- F2. Power Status LED
- F3. HDD Status LED
- F4. 4-in-1 Card Reader
SD/MMC/MS/MS Pro Memory Card
- F5. ODD/ Second HDD (Optional)
- F6. ODD Eject Button
- F7. USB 2.0 Port
- F8. Vertical Stand




Back Panel

- B1. Microphone Jack
- B2. Headphone/Line-out Jack
- B3. LAN Port
- B4. Kensington Lock
- B5. USB 2.0 Ports
- B6. D-sub Port
- B7. Power Jack (DC-in)
- B8. D-sub Port (Optional)
- B9. HDMI Port (Optional)



B6. D-sub port will not be functional and be covered with a cap if the system is equipped with Nvidia ION GPU.


Connecting the System



1 Connecting Monitor or LCD TVs

Digital and analog connections are available so the device can be connected to computer monitors, flat-panel displays, plasma or LCD TVs.

➤ **Analog:** Connect this to your computer monitor or LCD TVs.



➤ **Digital:** Connect this to your HDMI-enabled computer monitor, plasma or LCD TV.

Only XS35GT product will equip with HDMI feature.




➤ **Connecting HDTV or external amplifier with HDMI output**


XS35 supports HDMI 1.3 standard with the ability to transmit audio and video signal over the HDMI cable.




2 Connecting Keyboard/Mouse or USB Devices



3 Connecting LAN



4 Connecting Speakers and Microphone



5 Connecting Power




6 Powering on the system



A. Begin Installation


For safety reasons, please ensure that the power cord is disconnected before opening the case.

1. Unscrew one screw of the chassis cover.
2. Slide the cover backwards and upwards.





B. Memory Module Installation

1. Locate the SODIMM (DIMM1) slot on the mainboard.
2. Align the notch of the memory module with the one of the memory slot.




3. Gently insert the module into the slot in a 45-degree angle.
4. Carefully push down the memory module until it snaps into the locking mechanism.




C. HDD Installation


1. Mount HDD into the bracket with four screws.



2. As shown, install the HDD & bracket in the chassis and push it towards the direction as indicated by the red arrow to connect the HDD connector.




3. Tighten the HDD & bracket with three screws.



D. ODD or Second HDD Installation


1. Turn your XS35 upside down and remove another cover.
2. As shown, install the ODD/HDD Adapter Card with two screws and connect the cable to CN2/CN1.

➤ **For the ODD: install the ODD Adapter Card**




➤ **For a second HDD: install the HDD Adapter Card**

⚠ If you are installing a second HDD, tighten the two nuts first just as shown.




3. Mount ODD/HDD into the bracket with screws.

➤ **For the ODD**




➤ **For a second HDD**




4. As shown, install the ODD/HDD & bracket in the chassis and push it towards the direction as indicated by the red arrow to connect the ODD/HDD connector.

➤ **For the ODD**



➤ **For a second HDD**




5. Turn your XS35 upside down and tighten the ODD/HDD & bracket with one screw.





E. Complete

1. Replace the cover and refasten one screw.
2. Tear off the double sided protective membrane.



➤ **Using the Vertical Stand**

Install vertical stand and check that it is properly aligned, then tighten securely with one screw.



Safety Information

Read the following precautions before setting up a Shuttle PC.

CAUTION

Incorrectly replacing the battery may damage this co-puter. Replace only with the same or equivalent as recommended by Shuttle. Disposal of used batteries according to the manufacturer's instructions.

Laser compliance statement

The optical disc drive in this PC is a laser product. The drive's classification label is located on the drive.

CLASS 1 LASER PRODUCT

CAUTION: INVISIBLE LASER RADIATION WHEN OPEN.AVOID EXPOSURE TO BEAM.

➤ Informations de sécurité [Français]

Lire les précautions d'usage avant l'installation d'un Shuttle XPC.

ATTENTION

Ne pas replacer correctement la pile peut endom-mager l'ordinateur. Remplacez uniquement par la même ou un équivalent comme recommandé par Shuttle. Débarrassez-vous des piles usagées d'après les instructions du constructeur.

Etat de conformité du laser

Le lecteur de disque optique dans ce PC est un pro-duit à laser. Le label de classification du lecteur laser est situé sur le lecteur.

Produit laser de classe 1

Attention: Radiations laser à l'ouverture. Eviter l'exposition au faisceau laser.